

Damper actuator for operating air control dampers in ventilation and air-conditioning systems for building services installations

- For air control dampers up to approx. 1 m<sup>2</sup>
- Torque 5 Nm
- · Nominal voltage AC 100 ... 240 V
- · Control: Open-close or 3-point
- · Damper rotation: Form-fit 8 mm



Technical data			
Electrical data	Nominal voltage		AC 100 240 V, 50/60 Hz
	Nominal voltage range		AC 85 265 V
	Power consumption In	n operation	1.5 W @ nominal torque
	. Д	At rest	0.4 W
	F	or wire sizing	4 VA
	Connection		Cable 1 m, 3 x 0.75 mm <sup>2</sup>
Functional data	Torque (nominal torque	e)	Min. 5 Nm @ nominal voltage
	Direction of rotation		Reversible with switch 0 🗸 or 1 🤼
	Manual override		Gearing latch disengaged with pushbutton,
			self-resetting
	Angle of rotation		Max. 95°
			by means of adjustable, mechanical end stops
	Running time		150 s
	Sound power level		Max. 35 dB (A)
	Damper rotation		Form-fit 8 mm
	Position indication		Mechanical, pluggable
Safety	Protection class		II Totally insulated □
	Degree of protection		IP54 in any mounting position
	EMC		CE according to 89/336/EEC
	Low voltage directive		CE according to 73/23/EEC
	Mode of operation		Type 1 (to EN 60730-1)
	Ambient temperature r	range	−30 +50°C
	Non-operating tempera	ature	−40 +80 ° C
	Ambient humidity rang	je	95% r.H., non-condensating (EN 60730-1)
	Maintenance		Maintenance-free
Dimensions / Weight	Dimensions		See «Dimensions» on page 2
	Weight		Approx. 480 g

# Safety notes



- The damper actuator is not allowed to be used outside the specified field of application, especially not in aircraft or any other form of air transport.
- · Caution: Power supply voltage!
- Assembly must be carried out by trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The cable must not be removed from the device.
- When calculating the required torque, the specifications supplied by the damper manufacturers (cross section, design, installation site), and the air flow conditions must be observed.
- The device contains electrical and electronic components and is not allowed to be disposed
  of as household refuse. All locally valid regulations and requirements must be observed.



#### **Product features**

Simple direct mounting Simple direct mounting on the damper spindle by form-fit. The actuator, with its hollow shaft, is

placed over the 8 mm square spindle of the damper and secured by two screws.

Manual override Manual operation is possible with the self-resetting pushbutton (the gearing latch remains

disengaged as long as the pushbutton is pressed).

Adjustable angle of rotation Adjustable angle of rotation with mechanical end stops.

The actuator is overload-proof, requires no limit switches and automatically stops when the High functional reliability

end stop is reached.

## **Accessories**


	Description	Data sheet
Electrical accessories	Auxiliary switch SA	T2 - SA
	Feedback potentiometer PA	T2 - PA
Mechanical accessories	Shaft extension AV6-20	T2 - Z-LMA


#### **Electrical installation**

## Wiring diagrams

#### Note


- Caution: Power supply voltage!
- Other actuators can be connected in parallel. Please note the performance data.





Open-close control

3-point control





# **Direction of rotation**



# **Dimensions [mm]**

## **Dimensional drawings**





Damper spindle	Length
	min. 20





