


2. GM-4

Product Information

Damper actuators

GM



The complete range of damper actuators for general use in HVAC systems

Type	LM	NM	SM	AM	GM	LF	AF(R)	i010805
								
Torque	4 Nm	8 Nm	15 Nm	18 Nm	30 Nm	4 Nm	15 Nm	
Spring return function	-	-	-	-	-			
For dampers up to approx.	0.8 m²	1.5 m²	3 m²	3.6 m²	6 m²	0.8 m²	3 m²	

For more information, please contact your Belimo Representative or order any brochures you need by fax.

Fax to: **BELIMO** (address overleaf)

Please send us product brochures on the following damper actuators:

LM... NM... SM... AM... LF... AF... AFR... Electrical accessories

Please also send information on:

Motorized fire and smoke dampers
 Variable air-volume control (VAV-Control)
 Rotary-motion actuators and valves
 Linear-motion actuators and valves

Please call us back

Sender

Company:

Name:

Address:

Post code:

Country:

Tel.:

Fax:

E-Mail:

Date:

Selection table

Torque	30 Nm	GM24	GM220	GM240	GM24-SR
Nominal voltage	AC 24 V DC 24 V AC 230 V	● ● ●	● ●	● ●	● ●
Running time	135 s ± 15 s ≈ 180 s	●	● ●	● ●	●
Control	Open/Close Modulating	Single-wire 2-wire DC 0...10 V or 0...20 V phasect	● ● ●	● ● ●	●
Direction of rotation reversible (right/left)			● ●	● ●	● ●
Manual operation by pushbutton			● ●	● ●	● ●
Continuous position feedback					●

Note

Using BELIMO damper actuators

The actuators listed in this catalogue are intended for the operation of air dampers in HVAC systems.

Torque requirements

When calculating the torque required to operate dampers, it is essential to take into account all the data supplied by the damper manufacturer concerning cross sectional area, design, mounting and air flow conditions.

Damper actuators, Open/Close

GM24	4
GM220, GM240	5

Damper actuator, modulating

GM24-SR	6
Control/monitoring functions GM24-SR	7

Electrical accessories

S1, S2 Auxiliary switches	8
SZS Mid-position switch	9
P... Feedback potentiometer	10

Mechanical accessories


Damper linkage kit	11
Limit stop	11

Mounting instructions

	12
--	----



Wiring diagram



Technical data	GM24
Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
Nominal voltage range	AC 19.2...28.8 V, DC 21.6...26.4 V
For wire sizing	6 VA
Power consumption	3 W running, 1 W at end position
Connecting cable	0.9 m long, 3 x 0.75 mm ²
Direction of rotation	reversible with switch A/B
Torque	min. 30 Nm (at rated voltage)
Angle of rotation	mechanically limited to 95°
Running time	135 s ± 15 s
Sound power level	max. 45 dB(A)
Position indication	0...10 (0 = stop ⌂) and reversible indicator ☐ ☐
Protection class	□ (safety extra-low voltage)
Degree of protection	IP 54 (bottom cable entry)
Ambient temperature range	-30...+50 °C
Non-operating temperature	-40...+80 °C
Humidity test	to EN 60335-1
EMC	CE according to 89/336/EEC, 92/31/EEC, 93/68/EEC
Maintenance	maintenance free
Weight	2000 g

Dampers up to approx. 6 m²

**Open/Close actuator
(AC/DC 24 V)**

Single-wire or 2-wire control

Improved functional safety

The damper actuator has no limit switches and is overload-proof. It stops automatically when it reaches the damper or actuator end stop.

Easy functional check

A functional check of damper operation is simplicity itself: the gearing can be disengaged by simply pressing a pushbutton on top of the case. While the pushbutton remains depressed, the damper can be operated by hand.

Simple installation

The damper actuator is fitted with a universal spindle clamp for quick and easy mounting directly on the damper spindle. The actuator is supplied with an anti-rotation strap for fixing it in position.

Electrical accessories

- S1, S2 Auxiliary switches, page 8
- SZS Mid-position switch, page 9
- P... Feedback potentiometer, page 10

Mechanical accessories


- ZG-GM2 Damper linkage kit, page 11
- ZDB-GM Limit stop, page 11

Mounting instructions, page 12

Important

Read the notes about the use and torque requirements of the damper actuators on page 3.

Dimensions





Dampers up to approx. 6 m²

**Open/Close actuator
(AC 230 V)**

2-wire control

Improved functional safety

The damper actuator has no limit switches and is overload-proof. It stops automatically when it reaches the damper or actuator end stop.

Easy functional check

A functional check of damper operation is simplicity itself: the gearing can be disengaged by simply pressing a pushbutton on top of the case. While the pushbutton remains depressed, the damper can be operated by hand.

Simple installation

The damper actuator is fitted with a universal spindle clamp for quick and easy mounting directly on the damper spindle. The actuator is supplied with an anti-rotation strap for fixing it in position.

Electrical accessories

S1, S2 Auxiliary switches, page 8
Szs Mid-position switch, page 9
P... Feedback potentiometer, page 10

Mechanical accessories


ZG-GM2 Damper linkage kit, page 11
ZDB-GM Limit stop, page 11

Mounting instructions, page 12

Important

Read the notes about the use and torque requirements of the damper actuators on page 3.


Wiring diagram



Technical data

GM220, GM240	
Nominal voltage	AC 230 V 50/60 Hz
Nominal voltage range	AC 198...264 V
For wire sizing	10 VA @ 50 Hz, 13 VA @ 60 Hz
Power consumption	10 W @ 50 Hz, 13 W @ 60 Hz
Connecting cable	0.9 m long, 4×0.75 mm ²
Direction of rotation	reversible with switch A/B
Torque	min. 30 Nm (at rated voltage)
Angle of rotation	mechanically limited to 95°
Running time	≈ 180 s
Sound power level	max. 45 dB(A)
Position indication	0...10 (0 = stop ↗) and reversible indicator ■ ■
Protection class	I (with PE conductor)
Degree of protection	IP 54 (bottom cable entry)
Ambient temperature range	-30...+50 °C
Non-operating temperature	-40...+80 °C
Humidity test	to EN 60335-1
EMC	CE according to 89/336/EEC, 92/31/EEC, 93/68/EEC
Low Voltage Directive	CE according to 73/23/EEC
Maintenance	maintenance free
Weight	2000 g


Dimensions





p0016707

Wiring diagram



Technical data	GM24-SR
Nominal voltage	AC 24 V 50/60 Hz, DC 24 V
Nominal voltage range	AC 19.2...28.8 V, DC 21.6...28.8 V
For wire sizing	7 VA
Power consumption	3 W running, 2 W at rest
Connecting cable	0.9 m long, 5×0.75 mm ²
Control signal Y ₁	DC 0...10 V @ input resistance 100 kΩ (0.1 mA)
Control signal Y ₂	0...20 V phasecut @ input resistance 8 kΩ (50 mW)
Operating range	DC 2...10 V (at control signal Y ₁) 2...10 V phasecut (at control signal Y ₂)
Measuring voltage U	DC 2...10 V @ max. 0.5 mA (for 0...100% angle of rotation)
Synchronisation tolerance	± 5%
Direction of rotation (at Y = 0 V)	reversible with switch A/B at switch position A ↗ resp. B ↗
Torque	min. 30 Nm (at rated voltage)
Angle of rotation	mechanically limited to 95°
Running time	135 s ± 15 s
Sound power level	max. 45 dB(A)
Position indication	0...10 (0 = stop ↘) and reversible indicator ■ ■
Protection class	II (safety low voltage)
Degree of protection	IP 54 (bottom cable entry)
Ambient temperature range	-30...+50 °C
Non-operating temperature	-40...+80 °C
Humidity test	to EN 60335-1
EMC	CE according to 89/336/EEC, 92/31/EEC, 93/68/EEC
Maintenance	maintenance free
Weight	2000 g

Dampers up to approx. 6 m²

**Modulating damper actuator
(AC/DC 24 V)**

**Control DC 0...10 V or 0...20 V
phasecut**

Position feedback DC 2...10 V

Versatility of control

Combining two different methods of control in a single damper actuator ensures greater flexibility at the planning stage.

Improved functional safety

The damper actuator has no limit switches and is overload-proof. It stops automatically when it reaches the damper or actuator end stop.

Easy functional check

A functional check of damper operation is simplicity itself: the gearing can be disengaged by simply pressing a pushbutton on top of the case. While the pushbutton remains depressed, the damper can be operated by hand.

Simple installation

The damper actuator is fitted with a universal spindle clamp for quick and easy mounting directly on the damper spindle. The actuator is supplied with an anti-rotation strap for fixing it in position.

Electrical accessories*

S1, S2 Auxiliary switches, page 8

P... Feedback potentiometer, page 10

*SG...24 Positioners

*ZAD24 Digital position indicator

Mechanical accessories

ZG-GM2 Damper linkage kit, page 11

ZDB-GM Limit stop, page 11


Control and monitoring functions, p. 7

Mounting instructions, page 12


Important

Read the notes about the use and torque requirements of the damper actuators on page 3.


Dimensions





Remote control 0...100%



Minimum position




Override control




a	b	Reversing switch A	Reversing switch B
/-	/-	↻	↻
/-	/\	↻	↻
/\	/-	control mode	

Position indication and/or master-slave control (depending on position)



Function monitoring



Procedure

- AC 24 V at terminals 1 and 2
- Disconnect terminal 3 and/or 4:
 - For direction of rotation "A": actuator runs ↗
 - For direction of rotation "B": actuator runs ↘
- link terminals 2 and 3 or 2 and 4:
 - actuator runs in the opposite direction



Compatible with GM... and SM... damper actuators
(SM...: see documentation 2.SM-...)

Application

The auxiliary switch units S1 and S2 are intended for the signalling of end positions or for performing switching functions at any angular position.

Easy switch setting

A spindle provides a positive drive to the switch mechanism from the rotary motion of the damper actuator. The switching points of the microswitches can be set anywhere in the range from 0 to 10 by means of a dial and are then locked with a screw. The switch position can be read off at any time.

Simple installation

The auxiliary switch units S1 and S2 are suitable for direct mounting on Type GM... damper actuators or on Type P... feedback potentiometers. (The stack-mounting of two auxiliary switch units or of one unit and a Type Szs mid-position switch unit is not possible.)

Four extra-long screws are supplied for mounting the unit on Type GM24-SR and P... equipment.


Switch setting

1. Turn the damper actuator by hand to position 0.
2. Loosen the locking screw in the centre of the setting dial.
3. Rotate the dial until the arrow is pointing at the required switching point on the scale (0...10).
4. Re-tighten the locking screw.
5. Check the switching points by manual operation of the actuator; the setting dial turns at the same time. The microswitches operate whenever the arrow passes position 0 or 10 (white lines). The symbols indicate the respective switch positions.


Note

The reversible indicator plate and the pointer must be removed when using an auxiliary switch unit S1, S2.

Wiring diagram



Technical data	S1	S2
Number of switches	1xSPDT	2xSPDT
Switching capacity	6 A (2.5 A) AC 250 V	
Connecting cable	0.9 m, 3×0.75 mm ²	0.9 m, 6×0.75 mm ²
Switching point	Adjustable over full actuator rotation 0...10. Pre-setting by scale possible, settings lockable.	
Protection class	II (all-insulated)	
Degree of protection	IP 54	
Ambient temperature range	-30...+50 °C	
Non-operating temperature	-40...+80 °C	
Humidity test	to EN 60335-1	
Weight	150 g	210 g





**Compatible with GM24,
GM220, GM240 and SM24,
SM220, SM240 damper
actuators**

(SM...: see documentation 2.SM...)

Application

The Szs mid-position switch unit allows any required intermediate position to be preset.

Easy switch setting

A spindle provides a positive drive to the switch mechanism from the rotary motion of the damper actuator. The switching points of the microswitches can be set anywhere in the range from 0 to 10 by means of a dial and are then locked with a screw.

Remote control

As an alternative to using an Szs unit, it is better for many applications to be able to set the intermediate positions remotely, e.g. from the switchgear cubicle, instead of at the damper actuator itself. This arrangement requires the use of a positioner and a modulating damper actuator. Another advantage is that it allows several actuators to be connected in parallel.


Simple installation

The Szs mid-position switch unit is suitable for direct mounting on Type GM... damper actuators or on Type P... feedback potentiometers. (The stack-mounting of two Szs units or of one Szs unit and a Type S1 or S2 auxiliary switch unit is **not** possible.)

Note

The reversible indicator plate and the pointer must be removed when using a mid-position switch unit Szs.


Wiring diagram



Technical data

Szs

Connecting cable	0.9 m, 3×0.75 mm ²
Switching point	Adjustable over full actuator rotation 0...10. Pre-setting by scale possible, settings lockable.
Setting accuracy	2° rotation (at clamp)
Protection class	II (all-insulated)
Degree of protection	IP 54
Ambient temperature range	-30...+50 °C
Non-operating temperature	-40...+80 °C
Humidity test	to EN 60335-1
Weight	150 g





Compatible with GM... and SM... damper actuators
(SM...: see documentation 2.SM-...)

Application

The feedback potentiometer P... is used for the modulating control of dampers in conjunction with proportional action controllers with rigid feedback. It can also be used in conjunction with normal commercially-available systems for damper positions indication or as a positioner for actuators operating in parallel.

No adjustment needed


A spindle transmits the rotary motion of the actuator to the potentiometer. It is a positive drive and no adjustment is needed. If necessary, two feedback potentiometers can be mounted on top of each other.

Simple installation

The Type P... feedback potentiometer can be mounted directly on Type GM... damper actuators or on top of a second feedback potentiometer unit. A unit can also be stack-mounted with a Type S1 or S2 auxiliary switch unit or a Type S2S mid-position switch unit.


Four extra-long screws are supplied for mounting the unit on Type GM24-SR and P... equipment.

Wiring diagram




Types	Resistance data	
P 140	Feedback potentiometer	140 Ω
P 200	Feedback potentiometer	200 Ω
P 500	Feedback potentiometer	500 Ω
P 1000	Feedback potentiometer	1000 Ω
P 2000	Feedback potentiometer	2000 Ω
P 2800	Feedback potentiometer	2800 Ω

Technical data	P...
Resistance data	as above
Tolerance	± 5%
Rating	1 W
Linearity	± 2%
Resolution	1% min.
Residual resistance	max. 5% on both sides
Connecting cable	0.9 m, 3×0.75 mm ²
Degree of protection	IP 54
Ambient temperature range	-30...+50 °C
Non-operating temperature	-40...+80 °C
Humidity test	to EN 60335-1
Weight	150 g



Damper linkage kit ZG-GM2

**Application**

Damper linkage kit is employed when direct actuation of the damper is impossible and a linkage must be used.


Kit specification

- ① – Front mounting bracket
- ② – Rear mounting bracket
- ③ – Crank arm
- ④ – 2 ball joints KG10
 - 2 bolts M 6×16
 - 7 self-tapping screws

Assembly

- Screw the front ① and rear ② mounting brackets to the underside of the actuator baseplate
- Remove the V-bolt
- Bolt the crank arm ③ in position
- Mount the actuator in a suitable position on a secure base with 3 screws
- The 3-point fixing and the 10 mm clearance at the base ensure trouble-free mounting even when the mounting surface is irregular
- Adjust and tighten the damper linkage and ball joints

Limit stop ZDB-GM

**Application**

Limit stop ZDB-GM is used on damper actuators GM... when an angle of rotation of less than 90° needs to be limited mechanically but the damper does not have a fixed stop on its own. The limit can be set in 10° steps.


Assembly

- Fit the limit stop in the required angular position according to the instructions supplied


Mounting instructions for GM...

BELIMO®

Mounting instructions for damper spindles at least 63 mm long.



Mounting instructions for damper spindles at least 20 mm long or when overlapping the damper frame.



Preparations

- Place the actuator on the damper spindle
- Finger tighten the nuts on the V-bolt
- Bend the anti-rotation strap to fit, if necessary
- Fix the strap in position

Mounting and adjustment


- Move the damper to the closed position
- Disengage the gears by pressing the manual override pushbutton on the housing cover
- Turn the clamp to one division from the closed position and allow the gears to re-engage
- Align the actuator at 90° to the damper spindle
- Tighten the nuts on the V-bolt


Mounting and adjustment

- Disengage the gears by pressing the manual override pushbutton on the housing cover
- Turn the clamp to one division from the closed position and allow the gears to re-engage
- Remove the clip ② and take out the clamp ①
- Slip the clamp onto the damper spindle
- Move the damper to the closed position
- Fit the actuator onto the clamp
- Replace the clip
- Bend the anti-rotation strap to fit
- Fix the strap in position

Notes on both methods of mounting

- Select direction of rotation with switch A/B
- The indicator plate is reversible





Innovation, Quality and Consultancy: A partnership for motorizing HVAC actuators

Air applications



Standard actuators and spring-return actuators for air control dampers in HVAC systems



Safety actuators for motorizing fire and smoke extraction dampers



VAV systems for individual room air control



Mixing actuators and motorized ball valves for HVAC water circuits



Globe valves and intelligent linear actuators – also for leading makes of valve

Water applications

- Belimo Headquarters**
- CH BELIMO Holding AG
Guyer-Zeller-Strasse 6
8620 Wetikon, Switzerland
Tel. +41 (0)1 933 11 11
Telefax +41 (0)1 933 12 68
E-Mail: info@belimo.ch
Internet: http://www.belimo.ch
- Belimo Subsidiaries**
- AT BELIMO Automation
HR/ Handelsgesellschaft m.b.H.
HU/ Geiselbergerstrasse 26-32
SK/ 1110 Wien, Austria
SL Tel. ++43 (0)1 749 03 61-0
Telefax ++43 (0)1 749 03 61-99
E-Mail: info@belimo.at
- AU BELIMO Actuators Pty. Ltd.
Unit 10, 266 Osborne Avenue
Clayton South, VIC 3169
Australia
Tel. ++61 (0)3 9551 0201
Telefax ++61 (0)3 9551 0215
E-Mail: belimo@belimoactuators.com
- CA BELIMO Aircontrols (CAN), Inc.
5716 Coopers Ave., Units 14&15
Mississauga, Ontario L4Z 2E8
Canada
Tel. ++1 (1)905 712 31 18
Telefax ++1 (1)905 712 31 24
E-Mail: webmaster@belimo.com
- CH BELIMO Automation AG
Sales Switzerland
Guyer-Zeller-Strasse 6
8620 Wetikon, Switzerland
Tel. +41 (0)1 933 12 12
Telefax +41 (0)1 933 12 66
E-Mail: verkach@belimo.ch
Internet: http://www.belimo.ch
- DE BELIMO Stellantriebe
Vertriebs GmbH
Welfenstr. 27, Postfach 72 02 30
70599 Stuttgart, Germany
Tel. ++49 (0)711 1 67 83-0
Telefax ++49 (0)711 1 67 83-73
E-Mail: info@belimo.de
Internet: http://www.belimo.de
- ES BELIMO Ibérica
de Servomotores, S.A.
C/San Romualdo, 12-14
28037 Madrid, Spain
Tel. +34 91 304 11 11
Telefax +34 91 327 25 39
E-Mail: info@belimo.es
- FR BELIMO Servomoteurs
Z.A. de Country
33, Rue de la Régale
77181 Country, France
Tel. ++33 (0)1 64 72 83 70
Telefax ++33 (0)1 64 72 94 09
E-Mail: mail@belimo.fr
- Belimo Representatives and Agencies**
- AE BELIMO Automation
Middle East Office
P.O. Box 55427
Dubai, U.A.E.
Tel. ++971 (0)4 387 417
Telefax +971 (0)4 387 415
E-Mail: belimome@emirates.net.ae
- BE BELIMO Automation N.V.-S.A.
Leuvensesteenweg 613
1930 Zaventem, Belgium
Tel. ++32 (0)2 757 92 95
Telefax +32 (0)2 757 90 36
E-Mail: info@belimo.be
- BG BELIMO Bulgaria Ltd.
j.k. Lagera, 3 Smolyanska Str.
bl. 56, entr. B, ap. 50
1612 Sofia, Bulgaria
Tel. ++359 952 3470/1
Telefax +359 545 995
E-Mail: belimo@intech.bg
- CN BELIMO Automation UK Limited
The Lion Centre
Hampton Road West
Feltham, Middlesex, Great Britain
TW 13 6DS
Tel. ++44 (0)20 8755 4411
Telefax +44 (0)20 8755 4042
E-Mail: belimo@belimo.co.uk
- CN BELIMO Actuators Ltd.
Rm 605, Beijing Hai Chang
Edifice 44, Liang Ma Qiao Road
Chao Yang District
100016 Beijing, China
Tel. ++86 10 6462 1382
Telefax +86 10 6462 1383
E-Mail: beijing@belimo.com.hk
- CY R.E.S. Ltd.
P.O. Box 8297
Nicosia, Cyprus
Tel. +357 (0)2 51 10 07
Telefax +357 (0)2 49 65 47
E-Mail: reliance@spidernet.com.cy
- CZ BELIMO CZ (Ing. Ivar Mentzl)
Charkovská 16
10100 Praha 10, Czech Republic
Tel. +420 (0)2 717 40 311
Telefax +420 (0)2 717 43 057
E-Mail: info@belimo.cz
- DK BELIMO A/S
Thomas Heilstedsvej 7A
8660 Skanderborg, Denmark
Tel. ++45 86 52 44 00
Telefax +45 86 52 44 88
E-Mail: info@belimo.dk
- EE BELIMO Balticum AS
Töri 10 d
1131 Tallinn, Estonia
Tel. +372 6 140 811
Telefax +372 6 140 812
E-Mail: info@belimo.ee
- FI Oy Suomen BELIMO Ab
Iisinsirkkinkatu 2
00810 Helsinki, Finland
Tel. +358 (0)9 75 11 65 00
Telefax +358 (0)9 75 11 65 31
E-Mail: belimome@belimo.fi
- GR BELIMO Air Controls
29, Tagm, Plessa, Kalithea
GR 17674 Athens, Greece
Tel. ++30 (0)1 94 00 766
Telefax +30 (0)1 94 00 767
E-Mail: belimogr@tee.gr
- IE Safegard Systems Ltd.
Systems House, Unit 34
Southern Cross Business Park
Bray, Co Wicklow, Ireland
Tel. +353 (0)1 2761600
Telefax +353 (0)1 2761611
E-Mail: info@safegard.ie
- IL Shemer Representations
P.O. Box 296
56101 Yehud, Israel
Tel. ++972 3 536 51 67
Telefax +972 3 536 05 81
E-Mail: shemer@shemerco.il
- IN BELIMO Vitek Air Controls
C-114 Lancelot, First Floor
S.V. Road, Borivali (West)
Mumbai 400 092, India
Tel. ++91 22 806 21 63
Telefax +91 22 806 21 63
E-Mail: bvac@bom2.vsnl.net.in
- IS Hitataekni ehf.
Langholtsvegi 109
104 Reykjavik, Iceland
Tel. +354 5 88 60 70
Telefax +354 5 88 60 71
E-Mail: fridmar@hitataekni.is
- IT BELIMO Servomotori S.r.l.
Via Stezzano, 5
24050 Zanica BG, Italy
Tel. +39 035 67 26 82
Telefax +39 035 67 02 00
E-Mail: info@belimo.it
- KR HANMO Corporation
3rd Floor, Yeosam Blvd. 648-23
Gangnam-Ku, Seoul, Korea
Tel. ++82 2 3433 8225
Telefax +82 3433 8228
- LB Energy Center (EC)
Hamra, Leon Street, Shatilla,
Bldg. 4th Floor,
P.O. Box 113-6955
Beirut, Lebanon
Tel. ++961 (0)1 35 38 23
Telefax +961 (0)1 35 38 23
E-Mail: belimome@emirates.net.ae
- NL BELIMO Servomotoren B.V.
Radeweg 25, 8171 MD Vaassen
Postbus 300, 8160 AH Epe,
Netherlands
Tel. +31 57 58 68 36
Telefax +31 57 58 69 15
E-Mail: info@belimo.nl
- NO BELIMO Spjeldmotorer A/S
Konowsgate 5
0192 Oslo 1, Norway
Tel. ++47 22 70 71 71
Telefax +47 22 70 71 70
E-Mail: info@belimo.no
- PH BELIMO Actuators Philippines
Rm.# 507 Anita Build., 5th Floor
1300 Quezon Ave., Cor. South Ave.
1103 Quezon City, Philippines
Tel. +63 (2) 373 5440
Telefax +63 (2) 373 5424
E-Mail: philippines@belimo.com.hk
- RO Mano Construct srl
Dr Felix 53, ap 14, sector 1
Bucuresti, Romania
Tel. ++401 220 05 78
Telefax ++401 221 59 95
E-Mail: manoconstruct@fx.ro
- RU BELIMO Servomotors
Russia Ltd.
Nizhnyaya Pervomaiskaya,
46 Bld 1, Office 303
105203 Moscow, Russia
Tel. ++7 095 965 74 64
Telefax ++7 095 965 74 73
E-Mail: belimo.russia@mtu-net.ru
- SE BELIMO Spjälmotorer AB
Hägerstens Allé 88
129 37 Hägersten, Sweden
Tel. ++46 (0)8 88 07 00
Telefax ++46 (0)8 97 85 75
E-Mail: info@belimo.se
- SY Philippe A. Jebran
P.O. Box 7791
Damascus, Syria
Tel. ++963 11 231 6586
Telefax ++963 11 231 4052
E-Mail: belimome@emirates.net.ae
- TR BELIMO Otomatasyon A.S.
Hayriye Caddesi No. 16
TR-80060 Galatasaray-Istanbul
Turkey
Tel. ++90 (0)212 249 76 43
Telefax ++90 (0)212 243 02 58
E-Mail: info@belimo.com.tr
- TW Chianseng Enterprise Co. Ltd.
2F, No. 21, Tong Feng Street
Taipei, Taiwan
Tel. ++886 2 27 08 77 80
Telefax ++886 2 27 02 90 90
E-Mail: taiwan2@belimo.com.hk
- UA BELIMO Ukraine S.A.R.
34-A, Ul. Yurkovskaya, Appt.N°2
254080 Kiev, Ukraine
Tel./Telefax +380 44 463 7586
E-Mail: comaster@belimo.kiev.ua
- ZA BELIMO Actuators Southern Africa cc
P.O. Box 2483
Alberton 1450, South Africa
Tel. ++27 (0)11 868 5681
Telefax ++27 (0)11 900 2673
E-Mail: belimo@mega.co.za